MAGNET Field data collection software Online Activation Method



Step 1 - Product Activation

As mentioned, the **Online Activation** process requires that your mobile device has an active internet connection.

Note: It is recommended, but not necessary, to first have a MAGNET Enterprise company setup before attempting this method. By first having a Company within MAGNET Enterprise and then performing an Online Activation process for each or your MAGNET software purchases, your installations of MAGNET software as well as Topcon Sokkia hardware will become **manageable assets within your company**. Bonus!

Through USB Tethering, Get your Mobile Device Connected to the Internet

It is a common scenario to use a personal computer / laptop that is actively on the internet. After establishing a USB cable connection from your personal computer / laptop to the field device that MAGNET Field software has already been installed onto, your field device will share or be hosted with an inernet connection as well. USB tethering.

USB Tethering is the use of a personal computer / laptop to provide internet access through a USB cable to a connected mobile device (Topcon Tesla, GRS-1, or FC-2600, Sokkia Mesa or SHC-2600).



For more information contact Synergy Positioning Systems or visit the Synergy Positioning Systems website at www.synergypositioning.co.nz All branches: Phone 0800 867 266 Email: info@synergypositioning.co.nz

9	Step 2 - MAG	NET Enterprise Login 🛛 📈	
	Please enter you information:	Ir MAGNET Enterprise login	
	Login (e-mail)	magnet.field@topcon.com	
	Password	******	ş.
		Forgot Password 😽	ĝ.
	If you don't hav Create Account	e an account, please click the button	
	Create Accoun	t << Back Next >>	

Step 2 - MAGNET Enterprise Login

Within **Step 2** (shown above) you are offered the opportunity to enter your MAGNET Enterprise credentials. This will result in MAGNET Field data collection software going out to the internet and logging in to your exisiting MAGNET Enterprise Company.

If, at this stage, you do not currently belong to or have an account within a MAGNET Enterprise Company, you have the option to tap the **Create Account** button. This will begin the process of creating a new MAGNET Enterprise Company from scratch.

Stop. Do not create a new (MAGNET Enterprise Company) Account if you belong to one already. Creating duplicate accounts will need to be resolved on a case-by-case basis through the Topcon Technical Support teams.

If you already have a (MAGNET Enterprise Company) Account, enter in your MAGNET Enterprise **E-Mail Address** and **Password** within the fields provided and tap the Next button.

🔤 Step 3 - License Details 🏾 😽		
Please enter the Software Purcha Serial Number	serial number found on the se Certificate:	
Device Id	XXXX-XHFIW-N3SNW	TOPCON
		0
	<< Back Next >>	

Step 3 - License Details

Numbers, numbers everywhere. ..which ones to choose? Well, I'll tell you which Serial Number this is NOT. This step in the software activation process is not asking for the Serial Number of your hardware device (Topcon Tesla / Sokkia Mesa, FC / SHC-2600 controller, etc).

Instead, recall that after you purchased MAGNET Field software from either your Topcon Sokkia dealership or through the MAGNET Enterprise Store, you received a **MAGNET Field Software Purchase Certificate**. Within this MAGNET Field Software Purchase Certificate, you will find and use your unique Serial Number to activate your installation of MAGNET Field software.

A MAGNET Field Software Purchase Certificate looks like this:



Enter your Purchased MAGNET Field Serial Number

Referencing your unique (purchased) MAGNET Field Serial Number from your MAGNET Field Software Purchase Certificate, simply input the ten digits within the **Step 3 - License Details** screen.

The Device Identification (ID) field is automatically retrieved and populated for you by MAGNET Field software. This is the unique identification of the hardware that MAGNET Field software has been installed onto. ..keep going.



Step 4 - License Agreement

Last step will be to check the **Accept** checkbox at lower left and then tap the **Activate** button.

St	ep 4 - License	Agreement	2	
Pres Agree	s Accept to ac ement	cept the End Use	er License	
Soft	ware End User	License Agreem	ent	
IMP The Topo alon doct	ORTANT: PLE software prod con Positioning g with its asso imentation (co	ASE READ CARE uct provided to y y Systems, Inc. (ciated manuals ollectively, the	FULLY. You by "TPS") and	TOPCON
"Sof	tware") is owr	ed by TPS and y	our use is	
	ccept		Activate	

Online Activation of MAGNET Field Software Completed !!

	Product Activat	tion	
	License Type: Normal Expiration Date: 2013-01-11		Ð
	Module	Expiration Date	
	GIS GPS+ Optical	2013-01-11 2013-01-11 2013-01-11	TOPECON
	Robotic	2013-01-11 2013-01-11	Θ
e		Activate	



Currently logged in as ocantu. Sign Out . © 2012 Topcon TotalCare. jwe :: All rights reserved. Legal & Privacy.

